

**PHILIPS**

**dynalite** 

**DRC-GRMS-UL**

**Guest Room Relay  
Controller**



## Installation Instructions

Instructions d'installation

Installationsanweisungen

Instrucciones de instalación

Istruzioni per l'installazione

Installatie-instructies

インストール手順

安装指示

إرشادات التركيب

 **Devices must be installed by a qualified electrician in accordance with all national and local electrical and construction codes and regulations.**

Les appareils doivent être installés par un électricien diplômé conformément à tous les codes et réglementations électriques et de construction nationaux et locaux.

Die Geräte sind von einem qualifizierten Elektriker in Übereinstimmung mit allen geltenden Vorschriften zu installieren.

Los dispositivos deben ser instalados por un electricista calificado y cumpliendo todas las normas y regulaciones, tanto nacionales como locales, sobre instalaciones eléctricas y obras.



I dispositivi devono essere installati da un elettricista qualificato in conformità con le norme locali e nazionali vigenti in materia di costruzioni edilizie e installazione di impianti elettrici.



De apparaten moeten worden aangebracht door een gekwalificeerde elektricien en in overeenstemming met alle nationale en plaatselijke elektriciteits- en bouwvoorschriften.

装置を取り付ける際は、資格のある電気技師に依頼し、国および地域の電気および建設に関するすべての法令に従ってください。

根据国家/地区及当地的电气与建筑规范和法规，该设备必须由有资质的电工进行安装。

يجب تركيب الأجهزة من قبل فني كهربائي مؤهل وفقاً لكافة قوانين ونواح التركيب الكهربائي المحلي والوطني.






Output Ratings/Channel (CH)					
Load Type	CH1 - CH10	CH11	CH12	CH13 - CH14	OUT1 - OUT3
-□- General Use	16 A, 277 V ~	16 A, 277 V ~	16 A, 277 V ~ (N/O) 4 A, 250 V ~ (N/C)	16 A, 277 V ~	1A, 30V ~
-w- Resistive		1 A, 30 V ---	1 A, 30 V ---	1 A, 30 V ---	
💡 Incandescent	10 A, 120 V ~ 4.3 A, 277 V ~			10 A, 120 V ~ 4.3 A, 277 V ~	
⚡ Electronic Ballast	5 A, 120 V ~ 3 A, 277 V ~			5 A, 120 V ~ 3 A, 277 V ~	
Ⓜ Motor		9.8 FLA (1/2 HP), 120 V ~ 8 FLA (1 HP), 240 V ~	9.8 FLA (1/2 HP), 120 V ~ (N/O) 8 FLA (1 HP), 240 V ~ (N/O)		
▢ TV Rating	TV-8, 120 V ~	TV-5, 120 V ~	TV-5, 120 V ~	TV-8, 120 V ~	
NL Inrush Current	165 A	100 A	100 A	165 A	


**Output Ratings/Group**

CH3-CH6 ≤ 16A, CH7-CH10 ≤ 16A, CH13-CH14 ≤ 16A  
DRC-GRMS ≤ 112A


6



8




7




! IEC Overvoltage Category III


9 A








9 B



10




11




DRY CONTACT INPUTS

IN1	
IN2	
IN3	
C	
IN4	
IN5	
IN6	
C	
IN7	
IN8	
IN9	
C	


IN10	
IN11	
IN12	
C	
IN13	
IN14	
IN15	
C	
IN16	
IN17	
IN18	
C	



Installation example  
Exemple d'installation  
Installationsbeispiel  
Ejemplo de instalación  
Esempio di installazione  
Installatievoorbeeld  
設置例  
安装示例  
مثال التركيب




15




! Refer to product label for Earth Bar and Neutral Bar wire gauge and torque ratings.

16



17



**Federal Communications Commission (FCC) Compliance Notice: Radio Frequency Notice** – This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Any modifications not approved by the manufacturer of this device could void the user's authority to operate this device.

**This Class B digital apparatus complies with Canadian ICES-003: CAN ICES-3(B)/NMB-3(B). Cet appareil numerique de la classe B est conforme a la norme NMB-003 du Canada: CAN ICES-3(B)/NMB-3(B).**

**Installation of a home and building automation and control system shall comply with HD 60364-4-41. The temperature limits and current-carrying capacities for the communication wires specified in HD 384.5.523 shall not be exceeded.**



© 2019 Signify Holding. All rights reserved. Specifications are subject to change without notice. No representation or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance thereon is disclaimed. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. All other trademarks are owned by Signify Holding or their respective owners.



[www.lighting.philips.com/dynalite](http://www.lighting.philips.com/dynalite)

AZZ 444 0718 R13